# **USER'S GUIDE**



# PRODUCT LAYOUT:



#### PACKAGE CONTENTS:

- 1. RoadTalk main unit
- 2. 3.5mm audio cable

#### GETTING STARTED:

- 1. Connect the main unit to your car's power input or cigarette lighter plug.
- 2. On the RoadTalk main unit, search for a radio station between 87.5-108.0 by pressing the UP or DOWN arrow keys. Always try to use a station with minimal interference. (FM channels frequency may vary from city to city.) For optimal performance, change the FM channel when clarity is
- 3. On your cars FM radio, search for a radio station between 87.5-108.0. Always try to use a station with minimal interference. (FM channels frequency may vary from city to city.) For optimal performance, change the FM channel when clarity is poor.
- 4. Your car FM radio and RoadTalk must both be set to the same radio station.
- 5. Power "ON" the main unit by pressing the "POWER" button on the BoadTalk.

## CONNECTING AN AUDIO PLAYER:

1. To connect any audio player with a 3.5mm headphone jack to the RoadTalk, connect one end of the included audio cable to your audio player and the other end to the Road Talks "Audio IN". Your music will be heard through your cars FM stereo system.



2.

www.isound.net

**Bluetooth i.Sound:** The New Sound

www.isound.net

#### MOBILE PHONE SET-UP

- Have your Bluetooth™ capable cell phone ready. (To use this product in mobile communication, your mobile phone must be Bluetooth™ capable.)
- 2. Using your mobile phone, open the BlueTooth™ option and choose search for Bluetooth™ device. Your mobile phone will begin searching for the RoadTalk, once connected your phone will display "RoadTalk" enter "YES" on your cell phone. When prompted, enter the code 9999. NOTE: Bluetooth™ phone pairing may vary from phone to phone, refer to your mobile phone instructions for Bluetooth™ pairing tips.
- 3. When the RoadTalk is paired with a mobile phone the Bluetooth logo LED on the RoadTalk will flash repeatedly. To UNPAIR your mobile phone, turn your mobile phones Bluetooth™ feature off.
- 4. After you have successfully paired your mobile phone to the RoadTalk, you should not have to repeat the pairing process unless your mobile phone is shut down, reset or malfunctions. Each time you leave and return to your car, press the function button to automatically pair a previously paired mobile phone to the RoadTalk.

### ANSWERING INCOMING CALLS

To answer incoming phone calls, press the answer button on the RoadTalk or on your mobile phone. You will hear your incoming caller through your car stereos FM radio.

#### PLACING OUTGOING CALLS

- To dial phone numbers, use the keypad on your mobile phone.
- You can also use voice dialing if your mobile phone has a voice dialing feature. To use voice dialing, refer to your mobile phones user's guide. Press the ANSWER/REDIAL button one quick time to initiate voice dialing.

#### REDIALING:

 If your mobile phone supports redialing, you can redial the last number dialed by pressing the RoadTalks redial button twice.

# **AUDIO PLAYER and MOBILE PHONE:**

- You can have both your audio player and mobile phone connected to the RoadTalk simultaneously. Note: the Road Talk can only be paired to one mobile phone at a time.
- 2. If your mobile phone is A2DP compatible, you can send your mobile phones MP3 audio to the RoadTalk using the Bluetooth™ connection. Your MP3's will be transmitted to your car stereo's FM radio.
- 3. Audio players and mobile phones will both be heard through your cars FM radio.
- 4. When using an external audio device and a mobile phone, the audio will automatically pause when an incoming or outgoing call is received/placed.

# TROUBLESHOOTING:

**Problem:** Sound quality is poor?

**Solution:** Try a different FM station. You may need to try several different radio stations until you find a clear station.

**Problem:** My mobile phone will not pair to RoadTalk? **Solution:** Refer to your mobile phones user's guide for Bluetooth pairing.

**Problem:** Volume is very low?

Solution: Adjust the volume on your audio player.

**Problem:** My mobile phone's MP3 music is not being transmitted to my car's stereo system? **Solution:** Your mobile phone must be A2DP ready.

**Problem:** I cannot connect a second mobile phone to my RoadTalk?

Solution: The RoadTalk is only compatible with one mobile phone at a time. To connect a second phone you must first disconnect the previously paired phone by turning the paired phone's Bluetooth™ feature off and than pairing the phone you wish to use.

FOR TECHNICAL SUPPORT
PLEASE CONTACT: I-877-999-DREAM
or email us at support@dreamgear.net

iS